


DO NOT WELD BOTTOM CHORD
TO STABILIZER PLATE

GIRDER TYPE



DO NOT WELD BOTTOM CHORD
TO STABILIZER PLATE

GIRDER TYPE

